BMW Motorrad

Maintenance schedule

0492 - R 1150 GS Adventure

00 00 125 BMW Service with Annual Inspection (see Maintenance Schedule) (annually, initially at 10,000 km, then every 20,000 km)

Customer	Registration No.	Odometer reading	Equipment trim-level variant: 0645 - Integral ABS (partially integra	
Order No.	Date	Mechanic's + Manager's signature		
Reading fault-code	e memories with the BMW N	Notorrad diagnostic system		
Changing engine o	oil with engine at operating t	emperature, replacing oil filter		
23 00 510 Gearbox	x-oil change (maintenance)	*)	every two years	
33 00 501 Oil char	nge, rear wheel drive *)	ev	ery two years or every 40,000 km	
Checking battery a	cid level			
Cleaning and grea	sing battery terminals			
34 00 616 Changir (as part of mainten	ng brake fluid in Integral AB nance) *)	S wheel circuit, front	every two years	
34 00 617 Changir (as part of mainten	ng brake fluid in Integral AB nance) *)	S wheel circuit, rear	every two years	
34 00 608 Change (maintenance) *)	brake fluid in entire ABS co	ontrol circuit	every four years	
Checking clutch flu	iid level			
21 00 505 Change	the clutch fluid (during mai	ntenance) *)	every four years	
Checking operation	n of side-stand switch			
Greasing side stan	nd pivot			
12 31 610 Tension	Poly-V belt (associated wo	rk) *)	once only at 10,000 km	
Checking condition	of spark plugs			
Adjusting valve cle	arance			
Checking freedom	of movement of throttle cat	ole and checking for kinks and chafin	g	
34 00 650 Brake c	heck for BMW Motorrad Inte	egral ABS (as part of maintenance) *)	
Checking/adjusting	g synchronisation			
Checking tyre pres	sures and tread depth			
Checking spoke te	nsion		г	

Checking lights and signalling equipment Test ride as final inspection and function check			
*) Billed as a separate item	not as per the normal schedule		
BMW Motorrad, UX-VA-4 18.05.06		BMW recommends	Castrol