BMW Motorrad



Maintenance schedule

0186 - F 650 GS Dakar

00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

Customer	Registration No.	Odometer reading	Equipment trim-level variant: 0524 - Anti-lock braking system (ABS)	
Order No.	Date	Mechanic's + Manager's signature		
Pooding fault odd	momorios with the RMW M	storrad diagnostic system		
Reading fault-code memories with the BMW Motorrad diagnostic system Changing engine oil (engine and oil tank) and oil filter element				
Changing oil in tele	•			
Checking coolant I		noo\ *\		
17 00 505 Change coolant in system (maintenance) *) every four year Checking valve clearance				H
	se from intake air silencer			Ц
Replacing air filter element				
16 12 525 Replace the fuel filter (during maintenance) *) every 40,000 km				Ц
Checking clutch pl	-			
Checking spoke te	nsion, adjusting if necessary			
Checking front brake fluid level				
Checking brake-fluid level, rear brake				
Checking front brake pads for wear				
Checking front brake disc for wear				
Checking rear brak	ke pads for wear			
Checking rear brake disc for wear				
Testing brake system and checking for leaks				
32 72 510 Installing repair kit, piston for handbrake fitting (without every 40,000 bleeding) *)				
34 31 536 Installing piston repair kit in footbrake cylinder (without every 40,000 bleeding) *)				
34 00 548 Changing brake fluid, front brakes *) every two yea				
Changing brake flu	iid, rear brakes			

Checking chain, chain sprocket and chain pinion

Checking chain takeup roller and slider rail

Checking chain tension

Checking battery acid level

Cleaning and greasing battery terminals

Checking steering head bearing play

Checking operation of side-stand switch

Lubricating side stand

Lubricating footbrake lever

Checking specified torque of threaded fasteners with torque wrench: engine / main frame, engine / engine carrier and cylinder head / main frame

Checking specified torque of threaded fasteners with torque wrench: main frame / rear frame, frame bottom section / main frame and engine carrier / main frame

Checking specified torque of threaded fasteners with torque wrench: footrest plate / main frame and side stand / bottom truss

Checking specified torque of threaded fasteners with torque wrench: spring strut / angled lever / frame / reaction link

Checking specified torque of threaded fasteners with torque wrench: exhaust system

Checking tyre pressures and tread depth

Checking lights and signalling equipment

Final inspection and function check

Confirming BMW Service in on-board documentation

*) Billed as a separate item

BMW Motorrad, UX-VA-4 06.06.06

not as per the normal schedule



06/2006	ò
---------	---