## **BMW Motorrad**

Maintenance schedule

## 0559 - K 1200 LT

**00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule)** (annually, every 20,000 km)

Customer	Registration No.	Odometer reading	Equipment trim-level variant: 0538 - Cruise-control system
Order No.	Date	Mechanic's + Manager's signature	
Checking battery ch	arce state		r
Reading out fault me			L
Checking play of thr	-		Ľ
		ble, cruise-control system (for main	L
Engine-oil change, v			
	oil change (maintenance) *)	e	very two years or every 40,000 km
33 00 501 Oil chang	e, rear wheel drive *)	e	very two years or every 40,000 km
Changing brake fluid	d in wheel circuit, front		
Changing brake fluid	d in wheel circuit, rear		
34 00 608 Change k (maintenance) *)	prake fluid in entire ABS con	trol circuit	every four years
Brake check for BM	W Motorrad Integral ABS		
Checking clutch ope	erating fluid level		
21 52 506 Bleeding	hydraulic clutch system *)		every four years
Replacing intake air	filter element		
16 12 501 Replace 1	fuel filter (trim panels remov	ed) * <b>)</b>	every 40,000 km
Checking coolant le	vel and concentration		
17 00 505 Change coolant in system (maintenance) *)			every four years
Lubricating side-star	nd pivot mounts		
Checking centre-sta	nd pivot mounts		
Checking steering d	amper		
Checking rear whee	I bearing play by tilting whe	el	

Checking swinging arm bearing for play	
Checking valve clearance	
11 31 705 Additional work: Replace liner on chain tensioning rail, slide rail and thrust block (fuel tank / cylinder head cover removed) every 60,000 km *)	
Changing spark plugs	
Function test, engine start suppression	
Checking condition of tyres and wheels and checking tyre pressures	
Checking lights and signalling equipment	
Test ride as final inspection and function check	
Confirming BMW Service in on-board documentation	

\*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4 14.09.06

BMW recommends

09/2006