

BMW Motorrad

Maintenance schedule



0432 - R 1100 S

00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

_____	_____	_____	Equipment trim-level variant: 0524 - ABS II
Customer	Registration No.	Odometer reading	
_____	_____	_____	
Order No.	Date	Mechanic's + Manager's signature	

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Changing engine oil with engine at operating temperature, replacing oil filter	<input type="checkbox"/>
Change the oil in the gearbox, warmed to normal operating temperature	<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive *)	<input checked="" type="checkbox"/> every two years or every 40,000 km
16 12 525 Replace the fuel filter (during maintenance) *)	<input checked="" type="checkbox"/> every 40,000 km
Checking battery acid level	<input type="checkbox"/>
Cleaning and greasing battery terminals	<input type="checkbox"/>
Replacing intake air filter	<input type="checkbox"/>
Checking front brake discs for wear	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking brake-fluid level, front brakes	<input type="checkbox"/>
Checking rear brake discs for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections	<input type="checkbox"/>
Changing brake fluid, front brakes	<input type="checkbox"/>
Changing brake fluid, rear brakes	<input type="checkbox"/>
Checking clutch fluid level	<input type="checkbox"/>
21 00 505 Change the clutch fluid (during maintenance) *)	<input checked="" type="checkbox"/> every four years
Checking rear wheel bearing play by tilting wheel	<input type="checkbox"/>
Checking swinging-arm pivot mount	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>

Greasing side stand pivot		<input type="checkbox"/>
12 31 657 Repleace belt for generator (as part of maintenance) *)	every 40,000 km	<input type="checkbox"/>
Replacing spark plugs		<input type="checkbox"/>
Adjusting valve clearance		<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing		<input type="checkbox"/>
Checking/adjusting synchronisation		<input type="checkbox"/>
Checking tyre pressures and tread depth		<input type="checkbox"/>
Checking lights and signalling equipment		<input type="checkbox"/>
Test ride as final inspection and function check		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>

*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4
18.05.06

BMW recommends 